




LO-DRV_IN(JP30)
LO-DRV_OUT(JP32)
0502(MHJP8/MLJP8)

1 +15VCC
2 GATE(LO)IN
3 SYS-GND(RX-)
4 GATE(LO)OUT

EDM_ON-(JP31/Jp33)
0502(MHJP9/MLJP9)

1 EDM-ON-
2 SYS-GND

EXP-I/O(JP22)

EXP-OUT(JP24)

GX16-7

1 +15VCC GX16.1
2 GATE(LO) GX16.2
3 SYS-GND(RX-) GX16.3
4 RXD/RX+ GX16.4

EXP-I/O(JP23)

EXP-OUT(JP25)

GX16-7

1 RXD(TX-) GX16.5
2 +5VCC(TX-) GX16.6
3 EDM_ON- GX16.7

1 +5VCC(TX+) — JP26/Jp27
2 TXD/TX- — JP28/Jp29
1 RXD/RX+ —
2 SYS-GND(RX-) —
1 EDM_ON(C) —
2 EDM_ON(E) —
3 EDM_ON(C) —
4 EDM_ON(E) —

JP21

CES180503-2 PCB ASSEMBLY
EXP4 I/O BOARD

